

To facilitate the selection of switches, a coding system is utilised and consists basically of codes for the range, the model, and the wetted surface material. The other prefixes and suffixes are permutations of special features offered on most of the units.

Notes:

1. In Pressure Switches the elimination of one zero from the model number e.g., 2004 to 204 indicates Differential Adjustable.
2. In Differential Pressure Switches there is only one zero and the letter 'P' is added e.g., 204P. Reset Adjustable is indicated by suffixing model code with R/A e.g., 0 -204P – AO –R/A.

Other code guides (given later in the catalogue) apply to series 4000 (Panel and Field Mounting) and Series 2009 Temperature Switches.

If 'Offshore' Paint finish required, add the letters 'OS' at the beginning of the code number, i.e.: OS – PV 4 – 2001W – AO.

